


MOBILE RELAY

A S S O C I A T E S

dba Raycom



Instructions for Operating My Digital Simplex Portable Radio

Simplex radios are the simplest form of radio communication. Radios talk direct from radio to radio without the help of any infrastructure. Therefore, the simplex radios will operate during an emergency such as an earthquake, tornado, tsunami or wildfire when all other forms of radio communications fail due to problems with the infrastructure.

The following describes the use of a portable (hand-held) radio. To operate the radio:

1. Turn on the ON-OFF VOLUME control on top of the radio clockwise to turn on the radio and adjust the receive volume control to be the appropriate volume for your ambient noise condition. The volume has no effect on transmitting.
2. Turn the channel select knob on top of the radio to the proper channel for operation if you have more than one channel in the radio.
3. Press the MONITOR button to listen for co-channel users. (The MONITOR button is programmable on most radios and is usually the button below the PTT button, but it can be anywhere on the radio.) Most radios have an icon on the display that will light up to indicate you are in monitor which is typically an outline of a speaker or it will say MON. (Some radios are in monitor as long as you hold the button and some radios are PRESS to monitor and PRESS again to turn off the monitor.) If another party is using the frequency, you need to wait until they are finished before you talk on the radio.
4. If your radio is programmed for solely digital operation, you will only hear digital radio transmissions from NXDN (Kenwood and ICOM) type radios. You will not hear digital transmissions from DMR or MotoTrbo radios because their digital transmission is not compatible with your radio. Therefore, there can be other radio traffic on the frequency that you do not hear which can interfere with your transmission.
5. If your radio is programmed for mixed analog and digital mode, you will hear all digital and analog transmissions. Your radio will listen to NXDN (Kenwood and ICOM) transmissions and analog transmissions. You will hear the digital transmissions from DMR and MotoTrbo radios, but they will not be properly decoded and thus will not be understandable.
6. If the frequency is clear, press and hold the Push-To-Talk (PTT) button on the left side of the radio and speak in a normal voice from about 1 inch from the microphone. Release the PTT button to hear a response from the party you have called. Do not yell or scream as it will only degrade your intelligibility.

Mobile Relay Associates, LLC dba Raycom
15330 Vermont Ave.
Paramount, CA 90723

7. With simplex operation, each radio sends out its signal and the signal travels as far as it can directly to the other radios without the help from a repeater. Therefore, when you talk, some people will hear it and some will not hear you, depending upon where they are located. Typically, the people closer to you will hear you and the people further away may or may not hear you depending upon the distance and what obstructions are between you and them. As the signal continues to degrade, the signal may start to cut out at times and eventually the radio will no longer communicate. You will not get static in the reception of the radio signal, but you may get a digital / mechanical sound before it completely fails to communicate. Typical range with portable radios is about 0.6 mile in the city and a mobile radio will be about 6 miles in the city. Typical range with a portable radio in rural areas is about 2.4 miles in the countryside and about 18 miles for a mobile radio in the same area. *Digital radios typically get about 20% better range than an analog radio with everything else being equal.*

Battery and charger information for portable (hand-held) radios:

1. Some radios have a battery icon on the display to let you know the condition of the battery. If you do not have a battery icon, the radio will typically have a LED flash red whenever the battery is low. Some radios will have a different method of signaling a low battery which varies by radio model.
2. If your radio does not have a battery condition icon on the display, you need to pay more attention to how much you use the radio to have an idea of when to charge (or change) the battery.
3. Batteries that are very low can cause the radio to “reboot” whenever you press the PTT button or reboot continuously. Some radios will act very strangely and do things abnormally until the battery is charged or replaced.
4. When you are finished using the radio, turn it off and place it in the battery charger to recharge the battery. When the battery is fully charged, remove the radio from the charger if it will not be used for an extended period of time. Leaving the radio in the charger over night or over a weekend should not be a problem.
5. Most batteries have small, medium and/or large batteries which will determine the battery life for a particular radio. Typical numbers for small batteries are 8 hours use at 5-5-90 while large batteries are typically 12 hours at 10-10-80 which means 10% of the time you are transmitting, 10% of the time you are receiving a signal and 80% of the time your radio is in standby, meaning that it is turned on and awaiting for you to transmit or someone to call.
6. Transmitting takes the most power from the battery by a significant margin, so if you do not talk often, your battery will last significantly longer. Conversely, if you talk often, your battery will discharge more quickly.
7. If the radio has a HI / LOW power button, switching the radio to low power will extend the battery life, but it will reduce the range of your transmission.